



**Ice Teppanyaki**

# **HANDLEIDING OPERATION MANUAL**

Modelnr. \*712.038 - \*712.040 - \*712.045



## GEBRUIK

- 1) Zorg dat het apparaat voor aansluiting is ontdaan van alle verpakkingsmateriaal en folie en plaats de machine op een stabiele ondergrond.
- 2) Sluit het apparaat aan op een geaard stopcontact (netspanning 220-240V).
- 3) Schakel het apparaat in, om het apparaat voor te koelen (1 a 2 minuten vóór gebruik).
- 4) Vanwege de krachtige compressor kan het apparaat uitermate snel koelen. Dit zorgt ervoor dat de hoeveelheid massa snel in ijs wordt omgezet.
- 5) Model 712045 werkt met 2 onafhankelijke temperatuur-settingen.  
De linkerzijde van het apparaat is de Ice-Teppanyakiplaat (koel-/vriestemperatuur). Deze wordt hoofdzakelijk bestuurd door middel van de 'Cool' schakelaar.  
De rechterzijde is de 'verse' zijde, waar zowel de opbergruimte als de GN-bakjes zo koel mogelijk gegouden worden. Deze wordt bestuurd door middel van de 'Fresh' schakelaar.  
**Let op!** Dit zijn geen geïsoleerde ruimtes, deze functie is uitsluitend ondersteunend.
- 6) Modellen 712038 & 712040 hebben slechts 1 temperatuur-setting, bestuurd d.m.v. de 'Cool' schakelaar.

## SPECIFICATIES

Model	Pan afm. (mm)	Output	Voltage	Refrigerant (g)
*712.038	Ø350	740 W	220-240 V~/50 Hz	R290/145g
*712.040	500x500	1300 W	220-240 V~/50 Hz	R410A/1000g
*712.045	500x500	1500 W	220-240 V~/50 Hz	R410A/1000g

## BEDIENINGSPANEEL:



display 712038



display 712045



display 712040

## BEDIENINGSPANEEL INSTRUCTIES

Om het apparaat in werking te zetten volgt u, afhankelijk van het model dat u bezit, de volgende 2/3 stappen:

- 1) Stop de stekker in het stopcontact
- 2) Druk de "Cool" schakelaar in. De teppanyaki-plaat van het apparaat zal starten met koelen/vriezen.
- 3) Alleen van toepassing indien u model 712045 bezit:
  - ♦ Druk de "Fresh" schakelaar in. De garnerunit en opslagruimte van het apparaat zullen zo koel mogelijk gehouden worden.
  - ♦ De temperatuur-display geeft ten aller tijden automatisch de geproduceerde koel-/vriestemperatuur weer.

- ◆ Indien het apparaat om één of andere reden niet (goed) werkt, wordt er een error-code weergegeven en zal deze knipperen. U wordt verzocht de error-code lijst van deze handleiding te raadplegen.
- ◆ In het geval dat men de instellingen van de verse zijde (rechts) van het apparaat wil weten, drukt men op de + schakelaar en houdt deze minimaal 3 seconden vast. Indien men de schakelaar weer loslaat zal het scherm automatisch terugspringen op de aanwezige koeltemperatuur.
- ◆ Het voltage indicatiescherm geeft voltage/spanning weer.
- ◆ De Cool en Fresh functies zullen in werking gaan nadat deze knoppen ingedrukt worden, ook zal het controlelampje gaan branden om dit te bevestigen. Op het moment dat u de functie(s) wenst uit te zetten drukt u opnieuw op de knoppen. Deze knoppen werken als AAN/UIT schakelaar.

## INSTELLINGEN

- 1) Stel de gewenste (koeling/vries)temperatuur in (voor beide apparaat-functies):  
Houdt de "Cool" en/of "Fresh" schakelaar 3 seconden ingedrukt om naar de temperatuur-instellingen te gaan. De gewenste temperatuur wordt weergegeven in het scherm en knippert. Om deze temperatuur naar wens in te stellen gebruikt u de + en – knoppen, + staat voor een hogere temperatuur, – staat voor een lagere temperatuur. Nadat u de temperatuur heeft ingesteld kunt u eenmalig de schakelaar indrukken of u wacht een aantal seconden en het scherm zal automatisch terugspringen op de huidige koeltemperatuur.

## SNELONTDOOI FUNCTIE

Met het indrukken van het voetpedaal kan de ice-Teppanyakiplaat tussendoor snel ontdooid worden.

Door het pedaal ingedrukt te houden (zolang als gewenst) zal de ice-Teppanyakiplaat snel ontdooid, wat tussentijdse reiniging tussen de diverse gerechten vereenvoudigd.

## BELANGRIJK VOOR MODEL 712.045

De rechterzijde voorzien van garneerunit en onderkast kunnen alleen gekenmerkt en gebruikt worden als ondersteunende koeling, deze compartimenten zijn niet geschikt als koelkast of geschikt voor (terug)koelen van de te gebruiken ingrediënten.

## FOUT CODE LIJST

Error codering	Fout	Oorzaak	Oplossing
E00	Lage spanning	Lage spanning	Neem contact op met een gekwalificeerde monteur
E01	Hoge druk op compressor (waarschuwing)	1) Hoge druk op compressor 2) Druk-knop defect	

## PROBLEEMOPLOSSINGEN

Als het apparaat niet goed werkt, voer dan een inspectie en reparatie uit volgens de onderstaande tabel. Als de problemen aanhouden, neem dan contact op met een gekwalificeerde onderhoudsmonteur.

	Oorzaken	Controleer	Reparatie	Oplossing
Apparaat reageert niet/nauwelijks	Zekering kapot/gesmolten	Controleer de zekering	Vervang de zekering	Neem contact op met uw dealer
	Stekker niet goed in het stopcontact geplaatst	Controleer het stopcontact	Plaats de stekker opnieuw in het stopcontact	
Teveel geluid	Het apparaat staat instabiel/niet correct geplaatst.	Controleer de wielletjes op defecten	Plaats een object om stabiel/vast te zetten.	

### LET OP!

- ◆ Indien het apparaat plotseling niet (meer) goed functioneert. Zet het apparaat dan volledig uit, wacht 2 a 3 minuten en sluit het apparaat opnieuw aan.
- ◆ Indien u het apparaat niet gebruikt: haal de stekker uit het stopcontact.
- ◆ Indien u vermoedt dat het apparaat enige defecten laat zien wordt verzocht bovenstaande tabel er direct bij te pakken ter ondersteuning van het defect. U wordt verzocht (indien nodig) onderhoudstechnici in te schakelen.
- ◆ Open het apparaat nooit zelfstandig, vervang geen onderdelen en voer dan ook geen zelfstandige reparaties uit. De leverancier is niet verantwoordelijk voor schade veroorzaakt door foutieve reparatie of vervanging van onderdelen.
- ◆ Zorg dat het ontdooi-pedaal aan de onderzijde van het apparaat na gebruik altijd wordt ingeklapt om beschadigingen aan het apparaat of ongelukken te voorkomen.

## HOW TO USE

- 1) Ensure that the device is stripped of all packaging material and foil before being connected and place the machine on a stable surface.
- 2) Connected to a power voltage of 220-240V.
- 3) Switch on the machine, to pre-cool it for 1 or 2 minutes before usage.
- 4) Due to the installation of the high power compressor, its cooling speed is very rapid. So there will be ice stucked firmly to the pan, this will make it very hard to stir. When this occurs, please turn on the defrosting pedal, leave it on for a few seconds to allow defrosting.
- 5) Model 712045 is working with 2 independently controlled temperatures. The first one is the Cooling temperature (left side); this is working for the cooling-plate. Mainly controlled by the Cool-button. The other one is the Fresh temperature (right side); this side is working to cool the cabin and topping pans. Controlled by the 'Fresh' button.  
**Pay Attention!** *These are not isolated spaces, this is only supportive.*
- 6) Models 712038 & 712040 have only one temperature setting, controlled by the 'Cool' switch

## SPECIFICATIONS

Model	Pan size (mm)	Output	Voltage	Refrigerant (g)
*712.038	Ø350	740 W	220-240 V~/50 Hz	R290/145g
*712.040	500x500	1300 W	220-240 V~/50 Hz	R410A/1000g
*712.045	500x500	1500 W	220-240 V~/50 Hz	R410A/1000g

## CONTROL PANEL DISPLAY:



display 712038



display 712045



display 712040

## INSTRUCTION FOR DISPLAY

To start the device, depending on the model you own, follow the next 2/3 steps:

- 1) Put the plug in the socket.
- 2) Press the "Cool" switch. The teppanyaki-plate of the appliance will start cooling/freezing.
- 3) Only applicable if you own model 712045:
  - ◆ Press the "Fresh" switch. The garnishing unit and storage area of the device will be kept as cool as possible.
  - ◆ The temperature display automatically displays the produced cooling/freezing temperature at all times.
  - ◆ If the machine is not working properly, the temperature display will show the error code and it will flash. If needed, please check the error code list of this manual.

- ◆ In case you want to know the exact temperature of the fresh side (right) of the appliance, press the + switch and hold it for at least 3 seconds. If the switch is released again, the screen will automatically jump back to the available cooling temperature.
- ◆ The voltage display is showing the present voltage level used.
- ◆ The cooling and keep fresh indicator light will light up after pressing it. When an indicator light is on, it means the system starts up or is operational.
- ◆ The Cool and Keep Fresh functions will be activated after these button functions are pressed, the indicator light will light up to confirm this. At the moment you wish to switch off the function(s), press the switch again.

## SETTING

- 1) Setting the cooling temperature: Press the cool button for 3 seconds to enter into the cooling system settings, the temperature number is flashing in the display. To adjust the required temperature you can press + to raise the temperature or - to lower the temperature. After you finish the settings, you can press the cool button once to save the settings and to exit. Or you can wait for the system to exit automatically.
- 2) Keep fresh temperature: Press the keep fresh button for 3 seconds to enter into the cooling system settings, the temperature number is flashing in the display. To adjust the required temperature you can press + to raise the temperature or again - to lower the temperature. After you finish the settings, you can press the button once to save the settings and to exit. Or you can wait for the system to exit automatically.

## FAST DEFROST FUNCTION

The Ice-Teppanyaki plate can be rapidly defrosted by pressing the foot pedal.

By pressing the pedal (as long as desired) the Ice-Teppanyaki plate will defrost quickly.

## IMPORTANT FOR MODEL 712.045

The right-side of the machine with preparation unit and cupboard can only be characterized and used as support refrigeration, these compartments are not suitable as refrigerator or to cool the ingredients that are going to be used.

## ERROR CODE LIST

Error cost	Faulty	Faulty reason	Solution
E00	Lower power	Power low	Please contact a qualified technician
E01	high pressure warning for compressor	1) high pressure of compressor 2) pressure switch damaged	

## TROUBLESHOOTING

If you find out the ice machine is not working properly, please carry out inspection and repair according to the below table. If problems continue, please contact our maintenance department or local maintenance sites. Please do not remove any parts of the machine when you are not qualified with the malfunctions.

	<b>Causes</b>	<b>What to check</b>	<b>Treatment</b>	<b>Remarks</b>
No response at all	Melted fuse	Check the fuse	Change fuse	Please contact your dealer
	Bad socket connection	Check if it is plugged in	Replace the socket and plug	
Too much noise	Fried ice machine is not placed stable, in the right position.	Check the wheels	Use a pad	

## REMARKS

- ◆ If the ice machine stops working for unknown reasons, please wait for 2 to 3 minutes to re-connect the machine again.
- ◆ Please place your machine in the air vent position, and always disconnect the power while not working with the appliance.
- ◆ If the ice machine is showing any malfunction, please take actions as described in the above repair and caution table. Otherwise contact a qualified technician.
- ◆ If there's something wrong with the compressor or other main parts, please do not remove and never try to repair the appliance yourself. We are not responsible for any damages caused by the wrong operation towards the machine.
- ◆ After usage always close the defrosting pedal to prevent any damages to it.