



# \*304.070 **SMOKER** - EXPLODED VIEW / PARTLIST

Nomenclature **FM 2**  
Spare parts **FM 2**

Rep	Code	Qty	Pièce	Spare part
1	A15019	2	Poignée	Handle
2	48003	1	Couvercle	Lid
3	F01021	1	Grille	Grid
4	A14084	1	Bouton	Knob
5	A02008	1	Minuterie	Timer
6	A10001	1	Serre cable	Cord closer
7	D02145	1	Résistance	Heatingelement
8	C03006	1	Cordon avec prise	Cord with plug
9	A17008	1	Boule	Bowl
10	A13003	4	Pied	Foot
11	48006BOI	1	Boitier complet	Full controlbox
	F07007	1	Sciure 500 gr	Sawdust 500 gr

