


PARTS LIST

for

KitchenAid®

4 1/2 QT. STAND MIXER

EUROPEAN - TILT




***521.004**

COLOR VARIATION PARTS


For Variations of Model: 5KSM45E__4

Illus. No.	Part No.	DESCRIPTION
1	240291-1	Motor Housing White
2	9704649	Trim Band Black
3	240286-1	Planetary White
4	240253-1	End Cover White
5	240350-4	Lower Gearcase White
6	3184273	Pedestal & Foot White




BASE AND PEDESTAL UNIT

For Variations of Model: 5KSM45E__4



Illus. No.	Part No.	DESCRIPTION
1		Literature
	9709851	Use & Care Guide
	8212377	Repair Parts List
2	4162529	Screw Cap Kit
3	9709267	Lever, Latch
4	24450	Link, Latch
5	115792	Foot
6	*	Pedestal & Foot
7	16910	Pin, Hinge
8	103993	Screw, Latch Bearing
9	3184200	Latch, Link & Lever Assembly
10	9709055	Latch
11	8533912	Washer
12	110679	Screw
13	116241	Washer, Spring
14	3400020	Screw
15	9708470	Beater, Flat
16	4169926	Bowl And Base (4 1/2 Qt.)
17	9708471	Dough Hook
18	9706446	Wire Whip
19		Headlock
	3184262	White
20	3183690	Spring, Lock Lever
21	9706633	Shield, Pouring




CASE, GEARING AND PLANETARY UNIT

For Variations of Model: 5KSM45E__4

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing	15	9709627	Bevel Pinion & Center Gear	29	9706090	Washer, Shim
2	16897	Ring, Attachment Hub				30	9703903	Pinion, Gear
3	242765-2	Cap, Attachemnt Hub	16	240018-1	Pin (Vertical Center Shaft)	31	89411	Screw
4	9709194	Thumb Screw	17	3180163	Washer, Fiber	32	3400203	Screw, Set
5	**	Band, Trim	18	9705443	Pin, Groove	33	3400025	Screw
6	8533914	Lock Washer	19	4162324	Gasket, Transmission Case	34	67500-55	"O" Ring
7	3180161	Washer, Shim				35	311932	Screw, Self Tapping
8	4162897	Worm Gear	20	**	Lower Gear Case	36	**	Cover, End
9	240308	Worm Gear Bracket And Bearing	21	9704677	Pin, Groove	37	4162914	Screw
10	3400022	Screw	22	3180163	Washer, Fiber	38	240309-2	Worm & Pinion Gears Assembly
11	240210-2	Gear, Shaft and Pinion	23	9703904	Gear, Internal	39	4160474	Center Shaft & "O" Ring
12	9705444	Pin (Worm Gear)	24	103994	Screw, Special Planetary	40	9703438	Ring
13	240026	Shaft, Vertical Center	25	**	Planetary	41	9705132	RFI Filter
14	9705130	Gear, Attachment Hub Bevel	26	3184052	Agitator Shaft Assembly	42	9702311	Lead, Filter (to Control Board)
			28	240285	Ring, Planetary Drip			**Refer to Page 2 Color Variation Parts

MOTOR AND CONTROL PARTS

For Variations of Model: 5KSM45E_4



MOTOR AND CONTROL PARTS

For Variations of Model: 5KSM45E__4

Illus. No.	Part No.	DESCRIPTION
1	110679	Screw, Pivot
2	116241	Washer, Spring
3	9709276	Switch Lever And Stud
4	3183680	Spring, Control Plate
5	3184176	Speed Link & Cam
6	240205	Spring, Flat
7	240769	Screw, Stator
8	9701670	Field Assembly
9	9704324	Washer, Ball Bearing (Front)
10	W10068260	Screw
11	16998	Stud, Governor Drive
12	3180162	Washer, Spacing
13	W10068270	Washer
14	3184356	Seal, End
15	3180526	Bracket, Bearing Asm.
16	3180238	Washer
17	8533905	Nut, Machine
18	240680	Insert, Brush Holder
19	9706416	Brush, Carbon
20	9707926	Screw, Set
21	116286	Cap, Spring Seat
22	116287	Spring, Cap
23		Cap, Brush Holder
	3184212	Black
24	17830	Governor Assembly
25	240904-2	Control Plate Assembly
26		Cord, Power
	9702318	White (European)
27	9706596	Board, Phase Control
28	9708316	Armature & Bearng Assy (240V)
29	4162634	Sleeve, Motor Stud
30	3184086	Screw
31	3179908	Housing, Brush Holder
32	4162546	Brush Holder Assembly

ACCESSORY PARTS

For Variations of Model: 5KSM45E__4

Illus. No.	Part No.	DESCRIPTION
4164778		Mixer Attachment Pak (Includes Food Grinder (FGA), Food Strainer (FVSP), And Vegetable Slicer, (RVSA) (FPPA)
4164749		Food Grinder (FGA)
8211924		Grain Mill (KGMA)
4164768		Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FGA)
4164775		Fruit/Vegetable Strainer Parts (Use With FGA Model Only) (FVSP)
4164750		Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVSA)
3177975		Pouring Shield (KPS2CL)
4164824		Pasta Maker Plates (SNPA)
4164774		Fruit/Vegetable Strainer And Food Grinder (FVS/FGA)
3180617		Cover, Decorative (Cotton Polyester)
4162838		Food Tray (FT)
4164748		Juicer (JE)
4164747		Can Opener (CO)
4164803		Sausage Stuffer Kit (SSA)
3177924		Bowl Cover, Plastic Non-Sealing
4163337		Bowl, Stainless With Handle
3180262		Bowl, 3 Qt.
4162160		Bowl, Satin Stainless
9707963		Ice Cream Maker (KICA)
4176452		Pouring Shield (International)