



*523.010 ICE CRUSHER - PART LIST



NO	CODE	DESCRIPTION	Q'TY
1	AK/14-1	SWITCH	
2	AK/14-2	FRONT STICKER	
3	AK/14-3	FACE	
4	AK/14-4	CAP	
5	AK/14-5	SELF-PIERCING SCREW M4,2x19	
6	AK/14-6	GRATE	
7	AK/14-7	BUCKET	
8	AK/14-8	RIGHT SIDE OF CRUSHER BASE	
9	AK/14-9	LEFT SIDE OF CRUSHER BASE	
10	AK/14-10	INOX RIPPER BASE	
11	AK/14-11	SCREWS M3X16	
12	AK/14-12	STAR WASHER FOR M3	
13	AK/14-13	NUT M3	
14	AK/14-14	BUCKET MICRO SWITCH SUPPORT	
15	AK/14-15	BUCKET MICRO SWITCH WITH FOIL	
16	AK/14-16	STAINLESS STEEL BODY	
17	AK/14-17	CABLE GLAND	
18	AK/14-18	CORD WITH PLUG	
19	AK/14-19	SCREW M4,2X16	
20	AK/14-20	COVER MICRO SWITCH SUPPORT	
21	AK/14-21	COVER BASE	
22	AK/14-22	COVER PIN	
23	AK/14-23	COVER	
24	AK/14-24	COVER PIN	
25	AK/14-25	SPRING	
26	AK/14-26	COVER LOCK	
27	AK/14-27	CRUSHER	
27.1	AK/14-27.1	ALLEN SCREW M6X10	
27.2	AK/14-27.2	STAR WASHER M6	
27.3	AK/14-27.3	ELECTROMOTOR	
27.4	AK/14-27.4	ELECTROMOTOR BASE	
27.5	AK/14-27.5	STAR WASHER FOR M4	
27.6	AK/14-27.6	SCREW M4X12	
27.7	AK/14-27.7	BLADES MECHANISM	
27.8	AK/14-27.8	MILLED SCREW M4X20	
27.9	AK/14-27.9	SPLITTED CRUSHER	
27.10	AK/14-27.10	BIG WASHER FOR M5	
27.11	AK/14-27.11	STAR WASHER FOR M5	
27.12	AK/14-27.12	SCREW M5X12	
27.7.1	AK/14-27.7.1	BEARING	
27.7.2	AK/14-27.7.2	SHAFT NUT	
27.7.3	AK/14-27.7.3	SHAFT	
27.7.4	AK/14-27.7.4	SEALANT SPACER	
27.7.5	AK/14-27.7.5	MOVING BLADE	
27.7.6	AK/14-27.7.6	SPACER	
27.7.7	AK/14-27.7.7	STABLE BLADE	
27.7.8	AK/14-27.7.8	BASED SPACER	
27.7.9	AK/14-27.7.9	MOVING BLADE	
27.7.10	AK/14-27.7.10	MOVING BLADE	
27.7.11	AK/14-27.7.11	MOVING BLADE	
27.7.12	AK/14-27.7.12	SHAFT NUT	