



688.003 SALAMANDER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-AT936-001	BODY	1
2	Z-AT936-002	FOOT	4
3	Z-AT936-003	SCREW FOR FEET	4
4	Z-AT936-004	MESH HANDLE	2
5	Z-AT936-005	FAT TRAY	1
6	Z-AT936-006	MESH	1
7	Z-AT936-007	HEATING ELEMENT	1
8	Z-AT936-008	MOUNTING PLATE	4
9	Z-AT936-009	SCREW FOR MOUNTING PLATE	4
10	Z-AT936-010	RIGHT PLATE	1
11	Z-AT936-011	BACK PLATE	1
12	Z-AT936-012	SCREW FOR BACK PLATE	2
13	Z-AT936-013	SCREW FOR RIGHT PLATE	2
14	Z-AT936-014	LEFT PLATE	1
15	Z-AT936-015	HEATING INDICATOR	1
16	Z-AT936-016	PROPORTIONER	1
17	Z-AT936-017	PROPORTIONER KNOB	1
18	Z-AT936-018	POWER CORD JACKET	1
19	Z-AT936-019	POWER CORD	1
20	Z-AT936-020	HOLDING SCREW FOR TERMINAL	2
21	Z-AT936-021	CERAMIC TERMINAL	1
22	Z-AT936-022	TIMER KNOB	1
23	Z-AT936-023	TIMER	1
24	Z-AT936-024	ROUND TERMINAL	3
25	Z-AT936-025	INTERNAL CONNECTING WIRE	1
26	Z-AT936-026	FLAT TERMINAL	15
27	Z-AT936-027	GROUNDING SCREW	1