

688.051

BORDENWARMKAST - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-PW-001-03	TOP COVER BOARD	1
2	Z-PW-002	COLUMN	1
3	Z-PW-003	CERAMIC PANEL	1
4	Z-PW-004-03	TOP COVER INNER BOARD	1
5	Z-PW-005	THERMOSTAT	1
6	Z-PW-006-03	CONTROL PANEL	1
7	Z-PW-007	THERMOSTAT KNOB	1
8	Z-PW-008	DECORATING BOARD	1
9	Z-PW-009	SWITCH	1
10	Z-PW-010	CLIP	1
11	Z-PW-011	HINGE	2
12	Z-PW-012	HOLDER	4
13	Z-PW-013-03	INSULATION BOARD	1
14	Z-PW-014-03	DOOR	1
15	Z-PW-015	HANDLE	1
16	Z-PW-024	SCREW	2
17	Z-PW-016	HEAT ELEMENT BOARD	1
18	Z-PW-017-03	HEAT ELEMENT	1
19	Z-PW-018	HEATING ELEMENT CLIP	9
20	Z-PW-023	SCREW	12
21	Z-PW-019-03	LOWER BOARD	1
22	Z-PW-020	SUPPORT BAR	2
23	Z-PW-021	ABSBESTORS	1
24	Z-PW-022-03	BOTTOM BOARD	1
25	Z-PW-025	POWER CORD	1
26	Z-PW-026	POWER CORD JACKET	1
27	Z-PW-027-03	INNER ROUNDING BOARD	1
28	Z-PW-028-03	OUTER ROUNDING BOARD	1
29	Z-PW-029	ABSBESTORS	4
30	Z-PW-030	SCREW	32