

NO	CODE	DESCRIPTION	Q'TY
1	Z-FWT/DTFW-001	TEMPERATURE LIMIT CONTROLLER	
2	Z-FWT/DTFW-002	ELECTRICITY-LIN-NIP	
3	Z-FWT/DTFW-003	ELECTRICITY-LINE	
4	Z-FWT/DTFW-004	PLUG	
5	Z-FWT/DTFW-005	REPLACEMENT BRACKET	
6	Z-FWT/DTFW-006	REPLACEMENT ROD	
7	Z-FWT/DTFW-007	INDICATOR	
8	Z-FWT/DTFW-008	BRACKET FOR HEATER	
9	Z-FWT/DTFW-009	SCREWS FOR HEATER COVER	
10	Z-FWT/DTFW-010	HEAT PRESERVATION SHELL	
11	Z-FWT/DTFW-011	DIATHERMANOUS PLANK	
12	Z-FWT/DTFW-012	SWITCH OF POWER SUPPLY	
13	Z-FWT/DTFW-013	CONTROL THERMOSTAT	
14	Z-FWT/DTFW-014	KNOB	
15	Z-FWT/DTFW-015	HEATER	
16	Z-FWT/DTFW-016	HEATER COVER	
17	Z-FWT/DTFW-017	MOTHER BOARD	
18	Z-FWT/DTFW-018	FOOT	
19	Z-FWT/DTFW-019	SCREW FOR MOTHER BOARD	