

688.808 **FRITEUSE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-GF8F-001	TEMPERATURE LIMITER	
2	Z-GF8F-002	ELECTRIC TERMINAL BOX REAR	
3	Z-GF8F-003	ELECTRIC TERMINAL BOX FIXING	
4	Z-GF8F-004	GROUND CONNECTION SCREW	
5	Z-GF8F-005	POWER CORD	
6	Z-GF8F-006	POWER SWITCH	
7	Z-GF8F-007	EGO TEMPERATURE CONTROLLER	
8	Z-GF8F-007-01	CHINA TEMPERATURE CONTROLLER	
9	Z-GF8F-008	MIRCO SWICH	
10	Z-GF8F-009	STEEL COVER PLATE	
11	Z-GF8F-010	COVER PLATE HANDLE	
12	Z-GF8F-011	PLATE HANDLE FIXING SCREW	
13	Z-GF8F-012	TERMINAL BOX FIT-IN NUT SCREWS	
14	Z-GF8F-013	TERMINAL BOX FIX-IN NUT	
15	Z-GF8F-014	BODY FRAME	
16	Z-GF8F-015	OIL DRAINAGE TAP	
17	Z-GF8F-016	SILICON WASHER	
18	Z-GF8F-017	17 DRAINAGE L-SHAPE PIPE	
19	Z-GF8F-018	DRAINAGE MIDDLE PIPE	
20	Z-GF8F-019	DRAINAGE SEALING WASHER	
21	Z-GF8F-020	DRAINAGE HOSE	

688.808 **FRITEUSE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
22	Z-GF8F-021	RUBBER FEET	
23	Z-GF8F-022	OIL FILTER NET	
24	Z-GF8F-023	HEATING ELEMENT SUPPORTS	
25	Z-GF8F-024	HEATING ELEMENT	
26	Z-GF8F-025	FRYING BASKET	
27	Z-GF8F-026	HEATING ELEMENT PROTECTIVE	
28	Z-GF8F-027	HEATING INDICATOR LIGHT	
29	Z-GF8F-027-1	POWER INDICATOR LIGHT	
30	Z-GF8F-028	CONTROL PANEL	
31	Z-GF8F-029	KNOW OF TEMPERATURE CONTROLLER	
32	Z-GF8F-030	HANDLE OF FRYING BASKET	
33	Z-GF8F-A01	ELECTRICITY BOX(WITHOUT PANEL)	
34	Z-GF8F-A02	ELECTRICITY BOX	
35	Z-GF8F-A03	ELECTRICITY BOX WITH HEATING	