

712.030 **GEKOELDE SHOW/GEBAKSVITRINE -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-FCD72-001	CHARGING TUBE	1
2	Z-FCD72-002	POWER CORD	1
3	Z-FCD72-003	SOCKET	1
4	Z-FCD72-004	VOMPRESSOR	1
5	Z-FCD72-005	REAR BASE PANEL	1
6	Z-FCD72-006	DOOR WASHER	1
7	Z-FCD72-007	WASHER 1	1
8	Z-FCD72-008	WASHER 2	1
9	Z-FCD72-009	WASHER 3	1
10	Z-FCD72-010	REAR GLASS	1
11	Z-FCD72-011	LEFT PILLAR	1
12	Z-FCD72-012	SHELF	1
13	Z-FCD72-013	CAP OF EVAPORATOR HOLDER	1
14	Z-FCD72-014	FAN MOTOR FOR EVAPORATOR	1
15	Z-FCD72-015	LED LAMP	1
16	Z-FCD72-016	SMALL CAP	1
17	Z-FCD72-017	SCREW COVER	1
18	Z-FCD72-018	TOP COVER	1
19	Z-FCD72-019	ACCUMULATOR	1
20	Z-FCD72-020	EVAPORATOR	1
21	Z-FCD72-021	DOOR SWITCH UNIT	1
22	Z-FCD72-022	DOOR SWITCH	1
23	Z-FCD72-023	EVAPORATOR HOLDER	1
24	Z-FCD72-024	INSULATION SHEET	1
25	Z-FCD72-025	VENTILATED TRAY	1
26	Z-FCD72-026	DOOR GASKET	1
27	Z-FCD72-027	UPPER GEMEL	1
28	Z-FCD72-028	RIGHT PILLAR	1
29	Z-FCD72-029	UPPET DOOR FRAME	1

712.030 **GEKOELDE SHOW/GEBAKSVITRINE -** SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
30	Z-FCD72-030	DOOR HANDLE	1
31	Z-FCD72-031	DOOR FRAME	1
32	Z-FCD72-032	DOOR GLASS	1
33	Z-FCD72-033	SIDE MAGNETIC STRPE	1
34	Z-FCD72-034	BOTTOM DOOR FRAME	1
35	Z-FCD72-035	MAGNETIC STRIPE	1
36	Z-FCD72-036	BUSH	1
37	Z-FCD72-037	STEEL BALL	1
38	Z-FCD72-038	DOOR PIN	1
39	Z-FCD72-039	FRONT PANEL	1
40	Z-FCD72-040	MAINBOARD	1
41	Z-FCD72-041	CLIP FOR COMTROLLER	1
42	Z-FCD72-042	CIRULIT BOARD BOX	1
43	Z-FCD72-043	BOX COVER	1
44	Z-FCD72-044	COPPER PIPE	1
45	Z-FCD72-045	CONDEMSEF FAN	1
46	Z-FCD72-046	DRY FILTER	1
47	Z-FCD72-047	CONDENSER	1
48	Z-FCD72-048	BOTTOM BASE OF VOMPRESSOR	1
49	Z-FCD72-049	FIXED TRAY	1
50	Z-FCD72-050	MOTOR FOR THE ROTAIONAL RACK	1
51	Z-FCD72-051	BOTTOM COVER OF FIXED TRAY	1
52	Z-FCD72-052	UPPER COVER OF FINED TRAY	1
53	Z-FCD72-053	SEAL	1
54	Z-FCD72-054	PLANE BEARING	1
55	Z-FCD72-055	SWITCH	1
56	Z-FCD72-056	THE CLUTCH(DOWN)	1
57	Z-FCD72-057	THE CLUTCH(UP)	1