

***308.071 WAFFLE MAKERS - PART LIST, CARATE II**

NO	ART.-NR.	DESCRIPTION
1	35-00001	frame for single waffle machine
2	34-00001	base plate for single waffle machine
3	36-00001	thermostat
4	36-00255	knob
5	36-00200	timer
6	36-00150	signal light
7	36-00100	on/off switch
9	34-00701	distance ring
10	34-00400	fat tub
12	39-00001	foot
13	37-00001	electric cable
14	37-00550	cable relief
15	30-00401	handle 140 mm
16	34-00301	bow
17	34-00601	bottom cover
18	34-00202	plate
19	33-00008	lower heating element
20	31-40003	lower baking plate
21	9-80300-02	pin 4 mm
22	31-40002	upper baking plate
23	36-00500	clamp ledge
24	33-00007	upper heating element
25	34-00501	top cover
26	30-00042	fixing angle
27	37-00201	wiring for 1 upper part
28	37-00501	spiral protection
29	37-00101	wiring for 1 lower part