



Dualit® 310.001 - 310.003 TOASTER 4-SLOTS - SPARE PART LIST



NO	CODE	DESCRIPTION	USED ON
1	00499	Sandwich cage	D4B-A D4C-A D4V-A 4CB-A
2*	01362	Timer Switch - 2/3/4 Slot Or Combi	D4B-A D4C-A D4V-A 4CB-A
3*	00034	Selector Switch - 2/4 position rocker	D4B-A
4*	03201	Selector Switch - NewGen 4 slot	D4V-A
4*	00893	Rotary Selector Switch - Combi 2+1 & 2x2	4CB-A
5	01812	Selector Knob - NewGen 4 slot	D4V-A
5	01192	Selector Knob - 1/2/4	D4C-A
6	01111	Crumb Tray - 4 Slice	D4B-A D4C-A D4V-A 4CB-A
7	00899	Cover Stainless Steel - 4 Slice	D4B-A D4C-A D4V-A 4CB-A
8*	02516	Power Lead Cable - 2/3/4 slot	D4B-A D4C-A D4V-A 4CB-A
9*	00456	End Element - 4 bread, Combi 2x2, 2/4 sandwich and Thick & Thin.	D4B-A D4C-A D4V-A 4CB-A
10*	00457	Centre Element for all except 6 bread	D4B-A D4C-A D4V-A 4CB-A
11*	00036	Selector Switch - Thick & Thin	4CB-A
12*	00039	Neon Lamp - Pre Vario Combi & T 'n T	4CB-A
13*	02476	4 Slot Vario Thermal Fuse Rewire kit (Includes Part No 16~*)	D4B-A
14*	02477	4 Slot AWS/4 Slot Combi 2+2 Rewire kit w. Thermal Fuse (Includes Part No 16~*)	D4C-A, 4CB-A
15*	02478	4 Slot New Gen Thermal Fuse Rewire kit (Includes Part No 16~*)	D4V-A
16~*	02063	Thermal Fuse 4 Slot Toasters Manual Reset (From 2014.09)	D4B-A D4C-A D4V-A 4CB-A

*All items marked with a star should only be replaced by a Qualified Electrician.
 ~ This item can only be fitted by Dualit Ltd.

Dualit® 310.001 - 310.003 TOASTER 4-SLOTS - SPARE PART LIST



NO	CODE	DESCRIPTION	Q'TY
1	00041	Brass Connecting Links	2
2	00046	Feet - Non Adjustable	6
3	00047	Feet - Adjustable	6
4	00048	Ejector Knob	2
5	00322	Crumb Tray Handle	1
6	09000	Element Spanner	
7	00051	Sandwich Cage Handles	