



# Dualit® 310.002 - 310.004 TOASTER 6-SLOTS - SPARE PART LIST



NO	CODE	DESCRIPTION	USED ON
1	00030	Timer Switch	D6B
2	00893	Selector Switch	D6B
3	00914	Selector Knob	D6B
4	01320	Neon Lamp	D6B
5	00605	Crumb Tray	D6B
6	00900	Cover Stainless Steel - 6 Slot	D6B
7	02526	Power Lead Cable - 6 slot	D6B
8	00442	End Element - 6 slot only	D6B
9	00443	Centre Element for 6 bread only	D6B
10	01983	Wire kit 6 slot	D6B
11	01800	Timer knob	D6B

# Dualit® 310.002 - 310.004 TOASTER 6-SLOTS - SPARE PART LIST



NO	CODE	DESCRIPTION	Q'TY
1	00041	Brass Connecting Links	2
2	00043	Feet - Non Adjustable	6
3	01121	Feet - Adjustable	6
4	00044	Ejector Knob	2
5	00322	Crumb Tray Handle	1
6	09000	Element Spanner	
7	00051	Sandwich Cage Handles	