



417.013 HOT CHOCOLATE DISPENSER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZBC2501-001	BODY A	1
2	ZBC2501-002	BODY B	1
3	ZBC2501-003	LID A	1
4	ZBC2501-004	LID B	1
5	ZBC2501-005	BASE A	1
6	ZBC2501-006	BASE B	1
7	ZBC2501-007	TRAY	1
8	ZBC2501-008	HEATING PLATE HOLDER	1
9	ZBC2501-009	BLENDER	1
10	ZBC2501-010	HEATING PLATE	1
11	ZBC2501-011	PIPE	1
12	ZBC2501-012	BOWL	1
13	ZBC2501-013	SHAFT PIPE	1
14	ZBC2501-014	SCREW	1
15	ZBC2501-015	MANUAL BOOK	1
16	ZBC2501-016	CUP	1
17	ZBC2501-017A	O RING FOR 30 PLUNGER	1
	ZBC2501-017B	O RING FOR 10 HEATING PLATE	1
	ZBC2501-017C	O RING FOR SEALING	1
10	ZBC2501-018	ELECTRIA PLUG	1
19	ZBC2501-019	SAFETY FUSE	1
20	ZBC2501-020Z	HEATING PLATE SET(#20+#21)	1
	ZBC2501-020	HEATING PLATE ELEMENT	1
21	ZBC2501-021	HEATING PLATE PART	1
22	ZBC2501-022	MOTOR	1
23	ZBC2501-023	MOTOR HOLDER	1



417.013 **HOT CHOCOLATE DISPENSER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
24	ZBC2501-024	0-120 THERMOSTAT	1
25	ZBC2501-025	SHAFT	1
26	ZBC2501-026	0-90 THERMOSTAT	1
27	ZBC2501-027	FOOT	1
28	ZBC2501-028	HANDLE	1
29	ZBC2501-029	SPRING	1
30	ZBC2501-030	PLUNGER	1
31	ZBC2501-031	PIN	1
32	ZBC2501-032	SWITCH	1
33	ZBC2501-033	AC PLUG HOLDER	1
34	ZBC2501-034	LID BALL	1
35	ZBC2501-035	AC PLUG	1
36	ZBC2501-036	SCREW	1