

537.001 **MENGKNEEDMACHINE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-GM10-001	TOP COVER	1
2	Z-GM10-002	RETAINER	1
3	Z-GM10-003	MIXER HEAD AND COLUMN	1
4	Z-GM10-004	CENTER SHAFT	1
5	Z-GM10-005	GEAR-CENTER SHAFT	1
6	Z-GM10-006	SPACER	1
7	Z-GM10-007	WORM GEAR SHAFT	1
8	Z-GM10-008	WORM GEAR(BEFORE 2008)	1
-	Z-GM10-008-01	WORM GEAR(AFTER 2008)	1
9	Z-GM10-009	WORM GEAR SHAFT	1
10	Z-GM10-010	MOTOR 200-240V	1
	Z-GM10-010-1	MOTOR 100-120V	1
11	Z-GM10-011	CONTROL BOARD 200-240V	1
	Z-GM10-011-2	CONTROL BOARD 100-120V	1
12	Z-GM10-012	IC BOARD 200-240V	1
	Z-GM10-012-1	IC BOARD 100-120V	1
13	Z-GM10-013	PLANETARY GEAR	1
14	Z-GM10-014	INTERNAL GEAR	1
15	Z-GM10-015	HEAD RING	1
16	Z-GM10-016	PLANETARY HEAD	1
17	Z-GM10-017	PLANETARY SHAFT	1
18	Z-GM10-018	TAPERED PIN	1
19	Z-GM10-019	REAR PLATE OF COLUMN	1
20	Z-GM10-020	APRON	1
21	Z-GM10-021	BASE	1
22	Z-GM10-022	BOWL SUPPORT	1
23	Z-GM10-023	BOWL PIN	2
24	Z-GM10-024	LIFTING BAR	1
25	Z-GM10-025	FIXED ANGLE PLATE	1
26	Z-GM10-026	LIFTING BRACKET	1
27	Z-GM10-027	LIFTING HANDLE	1
28	Z-GM10-028	COMPRESSION SPRING	1
29	Z-GM10-029	BOWL(22.5CM)	1
30	Z-GM10-030	FLAT BEATER	1

537.001 **MENGKNEEDMACHINE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
31	Z-GM10-031	SPIRAL HOOK	1
32	Z-GM10-032	WIRE WHIP	1
33	Z-GM10-033	COVER PLUG	2
34	Z-GM10-034	COVER FIXED TUBE	1
35	Z-GM10-035	BALL BEARING	1
-	Z-GM10-035A	BALL BEARING WITH LID	1
36	Z-GM10-036	BALL BEARING	1
-	Z-GM10-036A	BALL BEARING WITH LID	1
37	Z-GM10-037	BALL BEARING	2
-	Z-GM10-037A	BALL BEARING WITH LID	2
38	Z-GM10-038	BALL BEARING	1
-	Z-GM10-038A	BALL BEARING WITH LID	1
39	Z-GM10-039	BALL BEARING	1
-	Z-GM10-039A	BALL BEARING WITH LID	1
40	Z-GM10-040	O-RING	1
41	Z-GM10-041	OIL SEAL	1
42	Z-GM10-042	OIL SEAL	1
43	Z-GM10-043	OIL SEAL	1
44	Z-GM10-044	SPRING PIN	2
45	Z-GM10-045	SPRING PIN	2
46	Z-GM10-046	C-RING	1
47	Z-GM10-047	C-RING	1
48	Z-GM10-048	C-RING	1
49	Z-GM10-049	C-RING	1
50	Z-GM10-050	C-RING	1
51	Z-GM10-051	KEY	3
52	Z-GM10-052	KEY	1
53	Z-GM10-053	KEY	1
54	Z-GM10-054	PLASTIC PLUG 3/4"	2
55	Z-GM10-055	PLASTIC PLUG 53MM	1
56	Z-GM10-056	CABLE CONNECTOR	1
57	Z-GM10-057	CABLE	1
58	Z-GM10-058	PLASTIC TUBE	1
59	Z-GM10-059	HEX BOLT	4

537.001 **MENGKNEEDMACHINE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
60	Z-GM10-060	HEX BOLT	5
61	Z-GM10-061	CAP SCREW	3
62	Z-GM10-062	MAC. SCREW	3
63	Z-GM10-063	CAP SCREW	2
64	Z-GM10-064	HEX BOLT	1
65	Z-GM10-065	MACH. SCREW	1
66	Z-GM10-066	MACH. SCREW	4
67	Z-GM10-067	MACH. SCREW	4
68	Z-GM10-068	MACH. SCREW	2
69	Z-GM10-069	MACH. SCREW	1
70	Z-GM10-070	SET SCREW	2
71	Z-GM10-071	NUT	3
72	Z-GM10-072	NUT	4
73	Z-GM10-073	NUT	1
74	Z-GM10-074	FLAT WASHER	1
75	Z-GM10-075	FLAT WASHER	2
76	Z-GM10-076	FLAT WASHER	2
77	Z-GM10-077	SPRING WASHER	4
78	Z-GM10-078	SPRING WASHER	6
79	Z-GM10-079	STICKER OF CONTROL PANEL	1
80	Z-GM10-080	BACK COVER (UNREMOVABLE)	1
80	Z-GM10-080-AR	BACK COVER (REMOVABLE)	1
81	Z-GM10-081	FRONT COVER (UNREMOVABLE)	1
-	Z-GM10-081-AR	FRONT COVER (REMOVABLE)	1
82	Z-GM10-082	SEAT OF MICRO SWITCH (BEFORE 2012 UNREMOVABLE-OLD)	1
83	Z-GM10-083	FIXED RING	1
84	Z-GM10-084	MACH. SCREW	4
85	Z-GM10-085	BOLT (UNREMOVABLE)	2
-	Z-GM10-085-AR	SET SCREW (REMOVABLE)	2
-	Z-GM10-085-AR1	SET SCREW (REMOVABLE)	2
86	Z-GM10-086	MACH. SCREW OF MICRO SWITCH FOR GUARD (UNREMOVABLE)	1
87	Z-GM10-086-AR	MICRO SWITCH FOR GUARD (REMOVABLE)	1
87	Z-GM10-087	MICRO SWITCH FOR LIFT	1

537.001 **MENGKNEEDMACHINE** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
88	Z-GM10-088	BOWL CLAMP	2
89	Z-GM10-089	BOLT	2
90	Z-GM10-090	SPRING WASHEER	2
91	Z-GM10-091	CARBON OF MOTOR-OLD (8x16MM)	2
91	Z-GM10-091A	CARBON OF MOTOR (7x11MM)	2
91	Z-GM10-091B	CARBON OF MOTOR-OLD (6x10MM)	2
92	Z-GM10-092	CARBON COVER	2
93	Z-GM10-093	LIMIT SWITCH SEAT	1
94	Z-GM10-094	TIE LINE-OLD TYPE ONLY	1
95	Z-GM10-095	MAC. SCREW	2
97	Z-GM10-097	LIMIT SWITCH SEAT	1
98	Z-GM10-098	SPRING	1
99	Z-GM10-099	LIMIT SWITCH STICK	1
100	Z-GM10-100	SPRING PIN	2
101	Z-GM10-101	MACH. SCREW	1
-	Z-GM10-A01	INTERNAL WIRING OF CONTROL BOARD	1
-	Z-GM10-A06	WIRING ASSEMBLY	1
-	Z-GM10-SA1	SAFETY GUARD ASSY COMPLETE-OLD	1
-	Z-GM10-SA2	SAFETY GUARD ASSY COMPLETE-NEW	1