

## 688.011 HETELUCHTOVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	Z-YXDM1E-001	BOTTOM BOARD	1
2	Z-YXDM1E-002	HEAT INDICATOR LIGHT	1
3	Z-YXDM1E-003	THERMOSTAT	1
4	Z-YXDM1E-004	RUBBER FEET	4
5	Z-YXDM1E-005	TIMER INDICATOR LIGHT	1
6	Z-YXDM1E-006	TIMER	1
7	Z-YXDM1E-007	INNER DOOR BOARD	1
8	Z-YXDM1E-008	DOOR GLASS	1
9	Z-YXDM1E-009	HANDLE	1
10	Z-YXDM1E-010	OUTER DOOR BOARD	1
11	Z-YXDM1E-011	HEAT ELEMENT	1
12	Z-YXDM1E-012	SEALING RUBBER STRIP	1
13	Z-YXDM1E-013	GRILL PLATE	1
14	Z-YXDM1E-014	SHELF	1
15	Z-YXDM1E-015	VENTILATION BOARD	1
16	Z-YXDM1E-016	MAIN FRAME	1
17	Z-YXDM1E-017	OUTER BOARD	1
18	Z-YXDM1E-018	REAR COVER	1
19	Z-YXDM1E-019	HEAT INSULATION BOARD	1
20	Z-YXDM1E-020	MOTOR AND FAN	1
21	Z-YXDM1E-021	ELECTRIC TERMINAL	1
22	Z-YXDM1E-022	SPRING	1
23	Z-YXDM1E-023	POWER CORD JACKET	1
24	Z-YXDM1E-024	POWER CORD	1
25	Z-YXDM1E-025	THERMAL INSULATION	1
26	Z-YXDM1E-026	TIMER KNOB	1
27	Z-YXDM1E-027	THERMOSTAT KNOB	1