



## 688.092 PERCOLATOR - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZBC290-105A1	Lid Handle	
2.3.4	ZBC290-105A2Z	Lifting Handles	
5	ZBC290-105A5	Inner Tank (Irreplaceable)	
6	ZBC290-105A6	Water Gauge Cap	
7	ZBC290-105A7	Water Gauge Cover	
8	ZBC290-105A8	Gauge Fixer	
9	ZBC290-105A9	Screw	
11.12.13.14. 16.18	ZBC290-105A11Z	Water Tap	
11	ZBC290-105A11	Tap Handle	
12	ZBC290-105A12	Tap Cover	
13	ZBC290-105A13	Tap Spring	
14	ZBC290-105A14	Tap Tie Bar	
15	ZBC290-105A15	Pc Water Gauge	
16	ZBC290-105A16	Tap Core	
17	ZBC290-105A17	Tap Gasket	
18	ZBC290-105A18	Tap Body	
19.20	ZBC290-105A19Z	Water Tap Silicone Circle & Nut	
21	ZBC290-105A21	Lid	
22	ZBC290-105A22	Screw	
23	ZBC290-105A23	Screw	
24	ZBC290-105A24	Coffee Filter	
25	ZBC290-105A25	Tube	
26	ZBC290-105A26	Screw	
27	ZBC290-105A27	Fixed Section (Irreplaceable)	
28	ZBC290-105A28	Indicator Lights (red)	
29	ZBC290-105A29	Indicator Lights (yellow)	
30	ZBC290-105A30	On/Off Switch	
31	ZBC290-105A31	Screw	
32	ZBC290-105A32	Hoop Of Heating Element	



## 688.092 PERCOLATOR - SPARE PART LIST

<b>NO</b>	<b>CODE</b>	<b>DESCRIPTION</b>	<b>Q'TY</b>
33	ZBC290-105A33	Bottom Plate (Irreplaceable)	1
34	ZBC290-105A34	88°C Automatic Thermostat	1
35	ZBC290-105A35	Feet Bracket (Irreplaceable)	1
36	ZBC290-105A36	Sealed Circle For Heating Element	1
37	ZBC290-105A37	Heating Element 950W	1
38	ZBC290-105A38	Fixed Piece Of Fuse	1
39	ZBC290-105A39	160°C Anti-Dry Thermostat	1
40	ZBC290-105A40-1	Fuse	1
	ZBC290-105A40	Inner Wires (With Fuse)	1
41	ZBC290-105A41	Base	1
42	ZBC290-105A42	Screw	1
43	ZBC290-105A43	Power cord	1