

688.120 **DIGITAL WATER BOILER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZBC110-1041	WATER PAN	1
2	ZBC110-1042	WATER FAUCET	1
3	ZBC110-1043	BASEBOARD OF THE CASE	1
4	ZBC110-1044	RUBBER FEET	4
5	ZBC110-1045	THE BOARD FOR INSTALL THE POWER WIRE	1
6	ZBC110-1046	BACK COVER BOARD	1
7	ZBC110-1047	CHAMBER	1
8	ZBC110-1048	HEATING THERMO PROBE	1
9	ZBC110-1049	HEATING ELEMENT	1
10	ZBC110-10410	INFLOWING BELLOWS	1
11	ZBC110-10411	BACK DAMPER	1
12	ZBC110-10412	THE BOARD FOR INSTALL THE CIRCUIT BOARD	1
13	ZBC110-10413	POWER WIRE LOCK	1
14	ZBC110-10414	POWER WIRE	1
15	ZBC110-10415	LED DISPLAY BOARD	1
16	ZBC110-10416	COVER PLATE OF THE DISPLAY BOARD	1
17	ZBC110-10417	COVER PLATE OF THE TOP	1
18	ZBC110-10418	CASE	1
19	ZBC110-10419	MOUNTING PLATE OF THE CHAMBER	1

688.120 **DIGITAL WATER BOILER** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
20	ZBC110-10420	COVER PLATE OF THE CHAMBER	1
21	ZBC110-10421	SILICONE SEAL	1
22	ZBC110-10422	MAGNETIC VALVE	1
23	ZBC110-10423	HIGH WATER LEVEL THERMO PROBE	1
24	ZBC110-10424	LOW WATER LEVEL THERMO PROBE	1
25	ZBC110-10425	DRINKABLE THERMO PROBE	1
26	ZBC110-10426	CIRCUIT BOARD	1
27	ZBC110-10427	POWER SWITCH	1
28	ZBC110-10428	BINDING POST	1
-	ZBC110-104A01	TEMPERATURE DISPLAY AND OPERATION BOARD	1