

688.170 PIZZAOVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZQP12	BACK BOTTOM PLATE	1
2	ZQP12	UPPER PLATE	1
3	ZQP12	ELECTRICAL PANEL	1
4	ZQP12	UPPER FRAME	1
5	ZQP12	THE RIGHT DOOR HINGE	1
6	ZQP12	THE LEFT DOOR HINGE	1
7	ZQP12	UPPER DOOR	1
8	ZQP12	LEFT AND RIGHT SIDES PANELS	2
9	ZQP12	INWALL PLATE	1
10	ZQP12	INWALL UPPER PLATE	1
11	ZQP12	INWALL BACK PLATE	1
12	ZQP12	HEATING TUBES	2
13	ZQP12	HAIR HEAT PIPE CLAMP	2
14	ZQP12	HEATING TUBE SUPPORT	4
15	ZQP12	PLATE OF HEATING SENSOR	2
16	ZQP12	LAMP SHADE	1
17	ZQP12	CERAMIC PLATE-STICK A	1
18	ZQP12	CERAMIC PLATE-STICK B	1
19	ZQP12	CERAMIC PLATE-LINING BOARD	1
20	ZQP12	INNER DOOR PANEL	1
21	ZQP12	OUTSIDE DOOR PANEL	1
22	ZQP12	GLASS	1
23	ZQP12	BOTTOM FRAME	1
24	ZQP12	PIZZA OVEN HANDLE	1
25	ZQP12	OPERATING LIGHT	1

688.170 **PIZZAOVEN** - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
26	ZQP12	POWER LIGHT	1
27	ZQP12	POWER SWITCH	1
28	ZQP12	BALCK RUBBER FEET	4
29	ZQP12-029	LAMP BULB	1
30	ZQP12-030	TEMPERATURE CONTROLLER	2
31	ZQP12-031	CERAMIC PLATE	1
32	ZQP12-032	TERMINAL CONNECTOR	1
33	ZQP12-033	POWER CORD (EURO)	1
34	ZQP12-034	THE TIMER (120 MINUTES)	1
35	ZQP12-035	THE TIMER DIAL SCALE (0-120 DEGREES)	1
36	ZQP12-036	THE THERMOSTAT DIAL SCALE (0-350 DEGREES)	2