

688.172 PIZZAOVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZQP22	BACK BOTTOM PLATE	1
2	ZQP22	UPPER PLATE	1
3	ZQP22	ELECTRICAL PANEL	1
4	ZQP22	UPPER FRAME	1
5	ZQP22	THE RIGHT DOOR HINGE	2
6	ZQP22	THE LEFT DOOR HINGE	2
7	ZQP22	UPPER DOOR	2
8	ZQP22	LEFT AND RIGHT SIDES PANELS	2
9	ZQP22	INWALL PLATE	1
10	ZQP22	INWALL UPPER PLATE	1
11	ZQP22	INWALL BACK PLATE	1
12	ZQP22	HEATING TUBES	3
13	ZQP22	HAIR HEAT PIPE CLAMP	2
14	ZQP22	HEATING TUBE SUPPORT	4
15	ZQP22	PLATE OF HEATING SENSOR	2
16	ZQP22	LAMP SHADE	1
17	ZQP22	CERAMIC PLATE-STICK A	1
18	ZQP22	CERAMIC PLATE-STICK B	1
19	ZQP22	CERAMIC PLATE-LINING BOARD	2
20	ZQP22	INNER DOOR PANEL	2
21	ZQP22	OUTSIDE DOOR PANEL	2
22	ZQP22	GLASS	2
23	ZQP22	BOTTOM FRAME	1
24	ZQP22	PIZZA OVEN HANDLE	2
25	ZQP22	OPERATING LIGHT	1

688.172 PIZZAOVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
26	ZQP22	POWER LIGHT	2
27	ZQP22	POWER SWITCH	1
28	ZQP22	BALCK RUBBER FEET	4
29	ZQP22-029	LAMP BULB	1
30	ZQP22-030	TEMPERATURE CONTROLLER	3
31	ZQP22-031	CERAMIC PLATE	2
32	ZQP22-032	TERMINAL CONNECTOR	1
33	ZQP22-033	POWER CORD (EURO)	1
34	ZQP22-034	THE TIMER (120 MINUTES)	1
35	ZQP22-035	THE TIMER DIAL SCALE (0-120 DEGREES)	1
36	ZQP22-036	THE THERMOSTAT DIAL SCALE (0-350 DEGREES)	3
37	ZQP22-037	CENTRE FRAME	1