



688.210 MICROWAVE OVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
D00	Z-MWO25-D000	DOOR ASS'Y	1
D01	Z-MWO25-D001	DOOR FRAME ASS'Y	1
D14	Z-MWO25-D014	HANDLE	1
D08	Z-MWO25-D008	DOOR GASKET	1
S35	Z-MWO25-S035	SCREW ST4X30PBHC	2
D24	Z-MWO25-D024	SCREW ST4X8PBHC	1
C00	Z-MWO25-C000	CONTROL PANEL ASS'Y	1
C18	Z-MWO25-C018	PCB ASS'Y	1
S02	Z-MWO25-S002	SCREW ST3X8PBHC	5
A01	Z-MWO25-A001	COVER WAVE GUIDE	1
A09	Z-MWO25-A009	PRANT COVER *I	1
B01	Z-MWO25-B001	BASE PLATE	1
B02	Z-MWO25-B002	LEG	4
B03	Z-MWO25-B003	ASS'Y BRACKET HINGE *U	1
E01	Z-MWO25-E001	MAGNETRON	1
E05	Z-MWO25-E005	H.V TRANSFORMER	1
E06	Z-MWO25-E006	H.V CAPACITOR	1
E07	Z-MWO25-E007	H.V DIODE	1
E10	Z-MWO25-E010	FILTER NOISE	1
E11	Z-MWO25-E011	FUSE	1
E13	Z-MWO25-E013	LAMP	1
E40	Z-MWO25-E040	THERMOSTAT 110/70 *H	1
E16	Z-MWO25-E016	POWER CORD ASS'Y	1
E35	Z-MWO25-E035	THERMOSTAT 160/95 *H	1
L01	Z-MWO25-L001	BOARD LATCH	1
L02	Z-MWO25-L002	LEVER SWITCH	1
L03	Z-MWO25-L003	MICRO SWITCH INTERLOCK	2
L04	Z-MWO25-L004	MICRO SWITCH MONITOR	1
L05	Z-MWO25-L005	HARNESS MAIN	1



688.210 MICROWAVE OVEN - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
S01	Z-MWO25-S001	SCREW CT3*8BBHC	1
S02	Z-MWO25-S002	SCREW ST3*8PBHC	8
S04	Z-MWO25-S004	SCREW ST4*10TBHC	15
S05	Z-MWO25-S005	SCREW ST4*12PWBHC	3
S06	Z-MWO25-S006	SCREW ST4*20TBHC	2
S07	Z-MWO25-S007	SCREW CT4*8TBHC	8
S08	Z-MWO25-S008	SCREW CT4*10HWBHC	2
S18	Z-MWO25-S018	SCREW $\phi 4 \times 6$	2
S21	Z-MWO25-S021	SPRING WASHER $\phi 4.1$	1
T01	Z-MWO25-T001	MOTOR TRAY	1
T09	Z-MWO25-T009	SHAFT STIRRER	1
W01	Z-MWO25-W001	FAN ASS'Y	1
W02	Z-MWO25-W002		1
W03	Z-MWO25-W003		1
Z01	Z-MWO25-Z001	HOLDER H.V.C	1
Z11	Z-MWO25-Z011	FAN STIRRER	1
W06	Z-MWO25-W006	DAMPER	1
Z22	Z-MWO25-Z022	SPONGE	1
Z24	Z-MWO25-Z024	CASE OUT	1
Z26	Z-MWO25-Z026	RUBBER NOISE	2
Z43	Z-MWO25-Z043	FRONT PLATE BRACKET	1
A11	Z-MWO25-A011	WAVE GUIDE BRACKET	1
Z40	Z-MWO25-Z040	WATER SEALING BRACKET	1