

*712.024 REFRIGERATED COUNTER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZRF100-111A1	SAFETY GLASS COVER	1
2	ZRF100-111A2	TOP PILLAR	1
3	ZRF100-111A3	GLASS COVER FRONT PILLAR	1
4	ZRF100-111A4	BOTTOM PILLAR	1
5	ZRF100-111A5	STRIP SEAL	1
6	ZRF100-111A6	UPPER PANEL	1
7	ZRF100-111A7	BACK PANEL	1
8	ZRF100-111A8	RIGHT SIDE PANEL	1
9	ZRF100-111A9	LEFT SIDE PANEL	1
10	ZRF100-111A10	FOAM BASE FOR HOUSING	1
11	ZRF100-111A11	BASE PLATE ASSEMBLY	1
12	ZRF100-111A12	FRONT PANEL	1
13	ZRF100-111A13	RIGHT FIXER FOR TOP PILLAR	1
14	ZRF100-111A14	LEFT FIXER FOR TOP PILLAR	1
15	ZRF100-111A15	CONDENSATOR	1
16	ZRF100-111A16	RIGHT FIXER FOR SAFETY GLASS COVER	1
17	ZRF100-111A17	LEFT FIXER FOR SAFETY GLASS COVER	1
18	ZRF100-111A18	GN PLATE	8
19	ZRF100-111A19	GN PAN SUPPORT BAR	3
20	ZRF100-111A20	UPPER COVER FOR CONDENSATOR	1
21	ZRF100-111A21	FAN MOTOR	1
22	ZRF100-111A22	COVER FOR CONDENSATOR	1
23	ZRF100-111A23	COMPRESSOR	1
24	ZRF100-111A24	CONTROL BRACKET	1
25	ZRF100-111A25	CONTROL PANEL	1
26	ZRF100-111A26	CONTROL BOX	1
27	ZRF100-111A27	TEMPERATURE PROBE	1
28	ZRF100-111A28	DEFROST PROBE	1
29	ZRF100-111A29	MAIN CIRCUIT BOARD	1
30	ZRF100-111A30	TEMPERATURE DISPLAY	1
31	ZRF100-111A31	SWITCH	1
32	ZRF100-111A32	ADJUSTABLE FEET	4
33	ZRF100-111A33	UPPER CONNECTION	1