



921.520 CHOCOLATE WARMER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
8	ZBC160-1081	Heat Pipes	1
3	ZBC160-1082	Circuit Board	1
4	ZBC160-1083	Sticker	1
9	ZBC160-1084	Sensor	1
5	ZBC160-1085	Switch	1
-	ZBC160-1086	Power Cord	1
6	ZBC160-1087	Power Socket	1
-	ZBC160-1088	Fuse	1
1	ZBC160-1089	Foot	4
2	ZBC160-10810	Bottom Plate	1
7	ZBC160-10811	Housing	1